WAL 165/6-A/B EN1

Montagehinweis / *instruction for installation*

Bestehend aus Rückwand und Holzgehäuse muss zuerst die Rückwand des Lautsprechers an die Wand/Decke montiert werden, danach fädelt man die ankommenden Kabelleitungen durch die Rückwand (dafür vorgesehene Löcher) und befestigt die Rückwand nun an die Wand. Jetzt schließt man die ankommenden Kabelleitungen an die jeweilige WAGO-Kunststoffklemme an. Nun setzt man das Holzgehäuse auf die montierte Rückwand, verschraubt das Gehäuse (mit den mitgelieferten Schrauben) „rechts und links" oder „unten und oben" an die Rückwand. Danach drückt/steckt man die Schraubenkappen (weiß) auf die Schrauben.

Consisting of a rear wall and wooden housing, the rear wall of the loudspeaker must first be mounted on the wall / ceiling, then the incoming cable lines are threaded through the rear wall (holes provided for this) and the rear wall is now attached to the wall. Now you connect the incoming cable lines to the respective one WAGO plastic clamp. Now you put the wooden housing on the mounted rear wall, screw the housing (with the supplied screws) „right and left" or „Below and above" on the back wall. Then you press / put the screw caps (white) on the screws.